


## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

The instructions for the examples discussed in this manual will focus on using the Model Tree to access the functionality of ABAQUS/CAE. Menu bar actions will be considered only when necessary (e.g., when creating a finite element mesh or postprocessing results).

### 2.3 Example: creating a model of an overhead hoist with ABAQUS/CAE

---

This example of an overhead hoist, shown in Figure 2–5, leads you through the ABAQUS/CAE modeling process by using the Model Tree and showing you the basic steps used to create and analyze a simple model. The hoist is a simple, pin-jointed framework that is constrained at the left end and mounted on rollers at the right end. The members can rotate freely at the joints. The frame is prevented from moving out of plane. A simulation is first performed in ABAQUS/Standard to determine the structure's static deflection and the peak stress in its members when a 10 kN load is applied as shown in Figure 2–5. The simulation is performed a second time in ABAQUS/Explicit under the assumption that the load is applied suddenly to study the dynamic response of the frame.



All members are circular steel rods, 5 mm in diameter.

#### Material properties

General properties:

$$\rho = 7800 \text{ kg/m}^3$$

Elastic properties:

$$E = 200 \times 10^9 \text{ Pa}$$

$$\nu = 0.3$$

**Figure 2–5** Schematic of an overhead hoist.

For the overhead hoist example, you will perform the following tasks:

- Sketch the two-dimensional geometry and create a part representing the frame.
- Define the material properties and section properties of the frame.
- Assemble the model.
- Configure the analysis procedure and output requests.
- Apply loads and boundary conditions to the frame.
- Mesh the frame.
- Create a job and submit it for analysis.
- View the results of the analysis.

A Python script for this example is provided in “Overhead hoist frame,” Section A.1, in the online version of this manual. When this script is run in ABAQUS/CAE, it creates the complete analysis model for this problem. Run the script if you encounter difficulties following the instructions given below or if you wish to check your work. Instructions on how to fetch and run the script are given in Appendix A, “Example Files.”

As noted earlier, it is assumed that you will be using ABAQUS/CAE to generate the model. However, if you do not have access to ABAQUS/CAE or another preprocessor, the input file that defines this problem can be created manually, as discussed in “Creating an input file,” Section 2.3 of Getting Started with ABAQUS/Standard: Keywords Version.

### 2.3.1 Units

Before starting to define this or any model, you need to decide which system of units you will use. ABAQUS has no built-in system of units. All input data must be specified in consistent units. Some common systems of consistent units are shown in Table 2–1.

**Table 2–1** Consistent units.

Quantity	SI	SI (mm)	US Unit (ft)	US Unit (inch)
Length	m	mm	ft	in
Force	N	N	lbf	lbf
Mass	kg	tonne ( $10^3$ kg)	slug	lbf s <sup>2</sup> /in
Time	s	s	s	s
Stress	Pa (N/m <sup>2</sup> )	MPa (N/mm <sup>2</sup> )	lbf/ft <sup>2</sup>	psi (lbf/in <sup>2</sup> )
Energy	J	mJ ( $10^{-3}$ J)	ft lbf	in lbf
Density	kg/m <sup>3</sup>	tonne/mm <sup>3</sup>	slug/ft <sup>3</sup>	lbf s <sup>2</sup> /in <sup>4</sup>

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE


The SI system of units is used throughout this guide. Users working in the systems labeled “US Unit” should be careful with the units of density; often the densities given in handbooks of material properties are multiplied by the acceleration due to gravity.

### 2.3.2 Creating a part

Parts define the geometry of the individual components of your model and, therefore, are the building blocks of an ABAQUS/CAE model. You can create parts that are native to ABAQUS/CAE, or you can import parts created by other applications either as a geometric representation or as a finite element mesh.

You will start the overhead hoist problem by creating a two-dimensional, deformable wire part. You do this by sketching the geometry of the frame. ABAQUS/CAE automatically enters the Sketcher when you create a part.

ABAQUS/CAE often displays a short message in the prompt area indicating what you should do next, as shown in Figure 2–6.



**Figure 2–6** Messages and instructions are displayed in the prompt area.

Click the **Cancel** button to cancel the current task. Click the **Previous** button to cancel the current step in the task and return to the previous step.

#### To create the overhead hoist frame:

1. If you did not already start ABAQUS/CAE, type **abaqus cae**, where **abaqus** is the command used to run ABAQUS.
2. Select **Create Model Database** from the **Start Session** dialog box that appears. ABAQUS/CAE enters the Part module. The Model Tree appears in the left side of the main window. Between the Model Tree and the canvas is the Part module toolbox. A toolbox contains a set of icons that allow expert users to bypass the menus in the main menu bar. For many tools, as you select an item from the main menu bar or the Model Tree, the corresponding tool is highlighted in the module toolbox so you can learn its location.
3. In the Model Tree, double-click the **Parts** container to create a new part.

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

The **Create Part** dialog box appears. ABAQUS/CAE also displays text in the prompt area near the bottom of the window to guide you through the procedure.

You use the **Create Part** dialog box to name the part; to choose its modeling space, type, and base feature; and to set the approximate size. You can edit and rename a part after you create it; you can also change its modeling space and type but not its base feature.

4. Name the part **Frame**. Choose a two-dimensional planar deformable body and a wire base feature.
5. In the **Approximate size** text field, type **4.0**.

The value entered in the **Approximate size** text field at the bottom of the dialog box sets the approximate size of the new part. The size that you enter is used by ABAQUS/CAE to calculate the size of the Sketcher sheet and the spacing of its grid. You should choose this value to be on the order of the largest dimension of your finished part. Recall that ABAQUS/CAE does not use specific units, but the units must be consistent throughout the model. In this model SI units will be used.

6. Click **Continue** to exit the **Create Part** dialog box.

ABAQUS/CAE automatically enters the Sketcher. The Sketcher toolbox appears in the left side of the main window, and the Sketcher grid appears in the viewport. The Sketcher contains a set of basic tools that allow you to sketch the two-dimensional profile of your part. ABAQUS/CAE enters the Sketcher whenever you create or edit a part. To finish using any tool, click mouse button 2 in the viewport or select a new tool.

**Tip:** Like all tools in ABAQUS/CAE, if you simply position the cursor over a tool in the Sketcher toolbox for a short time, a small window appears that gives a brief description of the tool. When you select a tool, a white background appears on it.

The following aspects of the Sketcher help you sketch the desired geometry:

- The Sketcher grid helps you position the cursor and align objects in the viewport.
- Dashed lines indicate the *X*- and *Y*-axes of the sketch and intersect at the origin of the sketch.
- A triad in the lower-left corner of the viewport indicates the relationship between the sketch plane and the orientation of the part.
- When you select a sketching tool, ABAQUS/CAE displays the *X*- and *Y*-coordinates of the cursor in the upper-left corner of the viewport.

7. Use the **Create Isolated Point** tool  located in the upper left corner of the Sketcher toolbox to begin sketching the geometry of the frame by defining isolated points. Create three points with the following coordinates:  $(-1.0, 0.0)$ ,  $(0.0, 0.0)$ , and  $(1.0, 0.0)$ . The positions of these points represent the locations of the joints on the bottom of the frame. Reset the view using

the **Auto-Fit View** tool  in the toolbar to see the three points.

Click mouse button 2 anywhere in the viewport to exit the isolated point tool.

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

8. The positions of the points on the top of the frame are not obvious but can be easily determined by making use of the fact that the frame members form  $60^\circ$  angles with each other. In this case *construction geometry* can be used to determine the positions of these points.

You create construction geometry in the Sketcher to help you position and align the geometry in your sketch. The Sketcher allows you to add construction lines and circles to your sketch; in addition, isolated points can be considered construction geometry.

For more information on construction geometry, see “Creating construction geometry,” Section 19.10 of the ABAQUS/CAE User’s Manual.


- a. Use the **Create Construction: Line at an Angle** tool  to create angular construction lines through each of the points created in Step 8. To select the angular construction line tool, do the following:
- Note the small black triangles at the base of some of the toolbox icons. These triangles indicate the presence of hidden icons that can be revealed. Click the **Create Construction: Horizontal Line Thru Point** tool  located on the middle-left of the Sketcher toolbox, but do not release mouse button 1. Additional icons appear.
  - Without releasing mouse button 1, drag the cursor along the set of icons that appear until you reach the angular construction line tool. Then release the mouse button to select that tool.

The angular construction line drawing tool appears in the Sketcher toolbox with a white background indicating that you selected it.

- Enter **60 . 0** in the prompt area as the angle the construction line will make with the horizontal.
  - Place the cursor at the point whose coordinates are  $(-1.0, 0.0)$ , and click mouse button 1 to create the construction line.
9. Similarly, create construction lines through the other two points created in Step 8.
- Create another angular construction line oriented  $60^\circ$  with respect to the horizontal through the point whose coordinates are  $(0.0, 0.0)$ .
  - Create two angular construction lines oriented  $120^\circ$  with respect to the horizontal through the points  $(0.0, 0.0)$  and  $(1.0, 0.0)$ . (You will have to exit the drawing tool by clicking mouse button 2 in the viewport and then reselect the tool to enter another angle value.)

The sketch with the isolated points and construction lines is shown in Figure 2–7. In this figure the

**Sketcher Options** tool  has been used to suppress the visibility of every other grid line.




**Figure 2-7** Frame construction geometry: points and lines (1 out of 2 grid lines visible).

10. If you make a mistake while using the Sketcher, you can delete lines in your sketch, as explained in the following procedure:

- a. From the Sketcher toolbox, click the **Delete Entities** tool .
- b. In the sketch, click on a line to select it.  
ABAQUS/CAE highlights the selected line in red.
- c. Click mouse button 2 in the viewport to delete the selected line.
- d. Repeat Steps b and c as often as necessary.
- e. Click mouse button 2 in the viewport or click **Done** in the prompt area to finish using the **Delete Entities** tool.

11. Create geometry lines to define the frame. While you are adding construction geometry and moving the cursor around the sketch, ABAQUS/CAE displays preselection points (for example, at the intersections of new construction geometry and existing construction geometry) that allow you to align objects precisely. Using the **Create Lines: Connected** tool  located in the upper-right corner of the Sketcher toolbox, connect the points with geometry lines. In addition, remember to create the geometry lines representing the internal truss bracing. The final sketch is shown in Figure 2-8.



**Figure 2-8** Frame geometry sketch.

12. From the prompt area (near the bottom of the main window), click **Done** to exit the Sketcher.

**Note:** If you don't see the **Done** button in the prompt area, continue to click mouse button 2 in the viewport until it appears.

13. Before you continue, save your model in a model database file.

a. From the main menu bar, select **File**→**Save**. The **Save Model Database As** dialog box appears.

b. Type a name for the new model database in the **File Name** field, and click **OK**. You do not need to include the file extension; ABAQUS/CAE automatically appends **.cae** to the file name.

ABAQUS/CAE stores the model database in a new file and returns to the Part module. The path and name of your model database appear in the main window title bar.

You should always save your model database at regular intervals (for example, each time you switch modules); ABAQUS/CAE does not save your model database automatically.


### 2.3.3 Creating a material

In this problem all the members of the frame are made of steel and assumed to be linear elastic with Young's modulus of 200 GPa and Poisson's ratio of 0.3. Thus, you will create a single linear elastic material with these properties.

#### To define a material:

1. In the Model Tree, double-click the **Materials** container to create a new material. ABAQUS/CAE switches to the Property module, and the **Edit Material** dialog box appears.
2. Name the material **Steel1**.

- Use the menu bar under the browser area of the material editor to reveal menus containing all the available material options. Some of the menu items contain submenus; for example, Figure B–7 shows the options available under the **Mechanical**→**Elasticity** menu item. When you select a material option, the appropriate data entry form appears below the menu.



**Figure 2–9** Submenus available under the **Mechanical**→**Elasticity** menu.

- From the material editor's menu bar, select **Mechanical**→**Elasticity**→**Elastic**. ABAQUS/CAE displays the **Elastic** data form.
- Type a value of **200.0E9** for Young's modulus and a value of **0.3** for Poisson's ratio in the respective fields. Use [Tab] or move the cursor to a new cell and click to move between cells.
- Click **OK** to exit the material editor.

### 2.3.4 Defining and assigning section properties

You define the properties of a part through sections. After you create a section, you can use one of the following two methods to assign the section to the part in the current viewport:

- You can simply select the region from the part and assign the section to the selected region.
- You can use the Set toolset to create a homogeneous set containing the region and assign the section to the set.

For the frame model you will create a single truss section that you will assign to the frame by selecting the frame from the viewport. The section will refer to the material **Steel** that you just created as well as define the cross-sectional area of the frame members.

#### Defining a truss section

A truss section definition requires only a material reference and the cross-sectional area. Remember that the frame members are circular bars that are 0.005 m in diameter. Thus, their cross-sectional area is  $1.963 \times 10^{-5} \text{ m}^2$ .

**Tip:** You can use the command line interface (CLI) in ABAQUS/CAE as a simple calculator. For example, to compute the cross-sectional area of the frame members,

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

click the  tab in the bottom left corner of the ABAQUS/CAE window to activate the CLI, type  $3.1416 * 0.005 ** 2 / 4.0$  after the command prompt, and press [Enter]. The value of the cross-sectional area is printed in the CLI.

### To define a truss section:

1. In the Model Tree, double-click the **Sections** container to create a section.  
The **Create Section** dialog box appears.

2. In the **Create Section** dialog box:
  - a. Name the section **FrameSection**.
  - b. In the **Category** list, select **Beam**.
  - c. In the **Type** list, select **Truss**.
  - d. Click **Continue**.

The **Edit Section** dialog box appears.

3. In the **Edit Section** dialog box:
  - a. Accept the default selection of **Steel** for the **Material** associated with the section. If you had defined other materials, you could click the arrow next to the **Material** text box to see a list of available materials and to select the material of your choice.
  - b. In the **Cross-sectional area** field, enter a value of  $1.963E-5$ .
  - c. Click **OK**.

### Assigning the section to the frame

The section **FrameSection** must be assigned to the frame.

### To assign the section to the frame:

1. In the Model Tree, expand the branch for the part named **Frame** by clicking the “+” symbol to expand the **Parts** container and then clicking the “+” symbol to expand the **Frame** item.
2. Double-click **Section Assignments** in the list of part attributes that appears.  
ABAQUS/CAE displays prompts in the prompt area to guide you through the procedure.
3. Select the entire part as the region to which the section will be applied.
  - a. Click and hold mouse button 1 at the upper left-hand corner of the viewport.
  - b. Drag the mouse to create a box around the truss.
  - c. Release mouse button 1.

ABAQUS/CAE highlights the entire frame.

4. Click mouse button 2 in the viewport or click **Done** in the prompt area to accept the selected geometry.

The **Edit Section Assignment** dialog box appears containing a list of existing sections.

5. Accept the default selection of **FrameSection**, and click **OK**.

ABAQUS/CAE assigns the truss section to the frame, colors the entire frame aqua to indicate that the region has a section assignment, and closes the **Edit Section Assignment** dialog box.

### 2.3.5 Defining the assembly

Each part that you create is oriented in its own coordinate system and is independent of the other parts in the model. Although a model may contain many parts, it contains only one assembly. You define the geometry of the assembly by creating instances of a part and then positioning the instances relative to each other in a global coordinate system. An instance may be independent or dependent. Independent part instances are meshed individually, while the mesh of a dependent part instance is associated with the mesh of the original part. For further details, see “Working with part instances,” Section 13.3 of the ABAQUS/CAE User’s Manual. By default, part instances are dependent.

For this problem you will create a single instance of your overhead hoist. ABAQUS/CAE positions the instance so that the origin of the sketch that defined the frame overlays the origin of the assembly’s default coordinate system.

#### To define the assembly:

1. In the Model Tree, expand the **Assembly** container and double-click **Instances** in the list that appears.

ABAQUS/CAE switches to the Assembly module, and the **Create Instance** dialog box appears.

2. In the dialog box, select **Frame** and click **OK**.

ABAQUS/CAE creates an instance of the overhead hoist. In this example the single instance of the frame defines the assembly. The frame is displayed in the 1–2 plane of the global coordinate system (a right-handed, rectangular Cartesian system). A triad in the lower-left corner of the viewport indicates the orientation of the model with respect to the view. A second triad in the viewport indicates the origin and orientation of the global coordinate system ( $X$ -,  $Y$ -, and  $Z$ -axes). The global 1-axis is the horizontal axis of the hoist, the global 2-axis is the vertical axis, and the global 3-axis is normal to the plane of the framework. For two-dimensional problems such as this one ABAQUS requires that the model lie in a plane parallel to the global 1–2 plane.

### 2.3.6 Configuring your analysis

Now that you have created your assembly, you can configure your analysis. In this simulation we are interested in the static response of the overhead hoist to a 10 kN load applied at the center, with the

left-hand end fully constrained and a roller constraint on the right-hand end (see Figure 2–5). This is a single event, so only a single analysis step is needed for the simulation. Thus, the analysis will consist of two steps overall:

- An initial step, in which you will apply boundary conditions that constrain the ends of the frame.
- An analysis step, in which you will apply a concentrated load at the center of the frame.

ABAQUS/CAE generates the initial step automatically, but you must create the analysis step yourself. You may also request output for any steps in the analysis.

There are two kinds of analysis steps in ABAQUS: general analysis steps, which can be used to analyze linear or nonlinear response, and linear perturbation steps, which can be used only to analyze linear problems. Only general analysis steps are available in ABAQUS/Explicit. For this simulation you will define a static linear perturbation step. Perturbation procedures are discussed further in Chapter 11, “Multiple Step Analysis.”

### Creating an analysis step

Create a static, linear perturbation step that follows the initial step of the analysis.

#### To create a static linear perturbation analysis step:

1. In the Model Tree, double-click the **Steps** container to create a step.  
ABAQUS/CAE switches to the Step module, and the **Create Step** dialog box appears. A list of all the general procedures and a default step name of **Step-1** is provided.
2. Change the step name to **Apply load**.
3. Select **Linear perturbation** as the **Procedure type**.
4. From the list of available linear perturbation procedures in the **Create Step** dialog box, select **Static, Linear perturbation** and click **Continue**.  
The **Edit Step** dialog box appears with the default settings for a static linear perturbation step.
5. The **Basic** tab is selected by default. In the **Description** field, type **10 kN central load**.
6. Click the **Other** tab to see its contents; you can accept the default values provided for the step.
7. Click **OK** to create the step and to exit the **Edit Step** dialog box.

### Requesting data output

Finite element analyses can create very large amounts of output. ABAQUS allows you to control and manage this output so that only data required to interpret the results of your simulation are produced. Four types of output are available from an ABAQUS analysis:

- Results stored in a neutral binary file used by ABAQUS/CAE for postprocessing. This file is called the ABAQUS output database file and has the extension **.odb**.
- Printed tables of results, written to the ABAQUS data (**.dat**) file. Output to the data file is available only in ABAQUS/Standard.

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

- Restart data used to continue the analysis, written to the ABAQUS restart (.res) file.
- Results stored in binary files for subsequent postprocessing with third-party software, written to the ABAQUS results (.fil) file.

You will use only the first of these in the overhead hoist simulation. A detailed discussion of printed output to the data (.dat) file is found in “Output to the data and results files,” Section 4.1.2 of the ABAQUS Analysis User’s Manual.

By default, ABAQUS/CAE writes the results of the analysis to the output database (.odb) file. When you create a step, ABAQUS/CAE generates a default output request for the step. A list of the preselected variables written by default to the output database is given in the ABAQUS Analysis User’s Manual. You do not need to do anything to accept these defaults. You use the **Field Output Requests Manager** to request output of variables that should be written at relatively low frequencies to the output database from the entire model or from a large portion of the model. You use the **History Output Requests Manager** to request output of variables that should be written to the output database at a high frequency from a small portion of the model; for example, the displacement of a single node.

For this example you will examine the output requests to the .odb file and accept the default configuration.

### To examine your output requests to the .odb file:

1. In the Model Tree, click mouse button 3 on the **Field Output Requests** container and select **Manager** from the menu that appears.

ABAQUS/CAE displays the **Field Output Requests Manager**. This manager displays an alphabetical list of existing output requests along the left side of the dialog box. The names of all the steps in the analysis appear along the top of the dialog box in the order of execution. The table formed by these two lists displays the status of each output request in each step.

You can use the **Field Output Requests Manager** to do the following:

- Select the variables that ABAQUS will write to the output database.
  - Select the section points for which ABAQUS will generate output data.
  - Select the region of the model for which ABAQUS will generate output data.
  - Change the frequency at which ABAQUS will write data to the output database.
2. Review the default output request that ABAQUS/CAE generates for the **Static, Linear perturbation** step you created and named **Apply load**.

Click the cell in the table labeled **Created**; that cell becomes highlighted. The following information related to the cell is shown in the legend at the bottom of the manager:

- The type of analysis procedure carried out in the step in that column.
- The list of output request variables.
- The output request status.

3. On the right side of the **Field Output Requests Manager**, click **Edit** to view more detailed information about the output request.

The field output editor appears. In the **Output Variables** region of this dialog box, there is a text box that lists all variables that will be output. If you change an output request, you can always return to the default settings by clicking **Preselected defaults** above the text box.

4. Click the arrows next to each output variable category to see exactly which variables will be output. The boxes next to each category title allow you to see at a glance whether all variables in that category will be output. A black check mark indicates that all variables are output, while a gray check mark indicates that only some variables will be output.

Based on the selections shown at the bottom of the dialog box, data will be generated at every default section point in the model and will be written to the output database after every increment during the analysis.

5. Click **Cancel** to close the field output editor, since you do not wish to make any changes to the default output requests.

6. Click **Dismiss** to close the **Field Output Requests Manager**.

**Note:** What is the difference between the **Dismiss** and **Cancel** buttons? **Dismiss** buttons appear in dialog boxes that contain data that you cannot modify. For example, the **Field Output Requests Manager** allows you to view output requests, but you must use the field output editor to modify those requests. Clicking the **Dismiss** button simply closes the **Field Output Requests Manager**. Conversely, **Cancel** buttons appear in dialog boxes that allow you to make changes. Clicking **Cancel** closes the dialog box without saving your changes.

7. Review the history output requests in a similar manner by right-clicking the **History Output Requests** container in the Model Tree and opening the history output editor.

### 2.3.7 Applying boundary conditions and loads to the model

Prescribed conditions, such as loads and boundary conditions, are step dependent, which means that you must specify the step or steps in which they become active. Now that you have defined the steps in the analysis, you can define prescribed conditions.

#### Applying boundary conditions to the frame


In structural analyses, boundary conditions are applied to those regions of the model where the displacements and/or rotations are known. Such regions may be constrained to remain fixed (have zero displacement and/or rotation) during the simulation or may have specified, nonzero displacements and/or rotations.

In this model the bottom-left portion of the frame is constrained completely and, thus, cannot move in any direction. The bottom-right portion of the frame, however, is fixed in the vertical

direction but is free to move in the horizontal direction. The directions in which motion is possible are called *degrees of freedom (dof)*.

The labeling convention used for the displacement and rotational degrees of freedom in ABAQUS is shown in Figure 2–10.

- 1 Translation in the 1-direction (U1).
- 2 Translation in the 2-direction (U2).
- 3 Translation in the 3-direction (U3).
- 4 Rotation about the 1-direction (UR1).
- 5 Rotation about the 2-direction (UR2).
- 6 Rotation about the 3-direction (UR3).



**Figure 2–10** Displacement and rotational degrees of freedom.

**To apply boundary conditions to the frame:**

1. In the Model Tree, double-click the **BCs** container.  
 ABAQUS/CAE switches to the Load module, and the **Create Boundary Condition** dialog box appears.
2. In the **Create Boundary Condition** dialog box:
  - a. Name the boundary condition **Fixed**.
  - b. From the list of steps, select **Initial** as the step in which the boundary condition will be activated. All the mechanical boundary conditions specified in the **Initial** step must have zero magnitudes. This condition is enforced automatically by ABAQUS/CAE.
  - c. In the **Category** list, accept **Mechanical** as the default category selection.
  - d. In the **Types for Selected Step** list, select **Displacement/Rotation**, and click **Continue**.  
 ABAQUS/CAE displays prompts in the prompt area to guide you through the procedure. For example, you are asked to select the region to which the boundary condition will be applied.

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

To apply a prescribed condition to a region, you can either select the region directly in the viewport or apply the condition to an existing set (a set is a named region of a model). Sets are a convenient tool that can be used to manage large complicated models. In this simple model you will not make use of sets.

3. In the viewport, select the vertex at the bottom-left corner of the frame as the region to which the boundary condition will be applied.
4. Click mouse button 2 in the viewport or click **Done** in the prompt area to indicate that you have finished selecting regions.

The **Edit Boundary Condition** dialog box appears. When you are defining a boundary condition in the initial step, all available degrees of freedom are unconstrained by default.

5. In the dialog box:
  - a. Toggle on **U1** and **U2** since all translational degrees of freedom need to be constrained.
  - b. Click **OK** to create the boundary condition and to close the dialog box.ABAQUS/CAE displays two arrowheads at the vertex to indicate the constrained degrees of freedom.
6. Repeat the above procedure to constrain degree of freedom **U2** at the vertex at the bottom-right corner of the frame. Name this boundary condition **Roller**.

7. In the Model Tree, click mouse button 3 on the **BCs** container and select **Manager** from the menu that appears.

ABAQUS/CAE displays the **Boundary Condition Manager**. The manager indicates that the boundary conditions are **Created** (activated) in the initial step and are **Propagated from base state** (continue to be active) in the analysis step **Apply load**.

**Tip:** To view the title of a column in its entirety, expand its width by dragging the dividing line between the column headings.

8. Click **Dismiss** to close the **Boundary Condition Manager**.

In this example all the constraints are in the global 1- or 2-directions. In many cases constraints are required in directions that are not aligned with the global directions. In such cases you can define a local coordinate system for boundary condition application. The skew plate example in Chapter 5, “Using Shell Elements,” demonstrates how to do this.

### Applying a load to the frame

Now that you have constrained the frame, you can apply a load to the bottom of the frame. In ABAQUS the term *load* (as in the Load module in ABAQUS/CAE) generally refers to anything that induces a change in the response of a structure from its initial state, including:

- concentrated forces,
- pressures,
- nonzero boundary conditions,

- body loads, and
- temperature (with thermal expansion of the material defined).

Sometimes the term load is used to refer specifically to force-type quantities (as in the **Load Manager** of the Load module); for example, concentrated forces, pressures, and body loads but not boundary conditions or temperature. The intended meaning of the term should be clear from the context of the discussion.

In this simulation a concentrated force of 10 kN is applied in the negative 2-direction to the bottom center of the frame; the load is applied during the linear perturbation step you created earlier. In reality there is no such thing as a concentrated, or point, load; the load will always be applied over some finite area. However, if the area being loaded is small, it is an appropriate idealization to treat the load as a concentrated load.

**To apply a concentrated force to the frame:**

1. In the Model Tree, click mouse button 3 on the **Loads** container and select **Manager** from the menu that appears.

The **Load Manager** appears.

2. At the bottom of the **Load Manager**, click **Create**.

The **Create Load** dialog box appears.

3. In the **Create Load** dialog box:

- a. Name the load **Force**.

- b. From the list of steps, select **Apply load** as the step in which the load will be applied.

- c. In the **Category** list, accept **Mechanical** as the default category selection.

- d. In the **Types for Selected Step** list, accept the default selection of **Concentrated force**.

- e. Click **Continue**.

ABAQUS/CAE displays prompts in the prompt area to guide you through the procedure. You are asked to select a region to which the load will be applied.

As with boundary conditions, the region to which the load will be applied can be selected either directly in the viewport or from a list of existing sets. As before, you will select the region directly in the viewport.

4. In the viewport, select the vertex at the bottom center of the frame as the region where the load will be applied.
5. Click mouse button 2 in the viewport or click **Done** in the prompt area to indicate that you have finished selecting regions.

The **Edit Load** dialog box appears.

6. In the dialog box:

- a. Enter a magnitude of **-10000.0** for **CF2**.



5. In the lower portion of the dialog box, examine the element shape options. A brief description of the default element selection is available at the bottom of each tabbed page.  
Since the model is a two-dimensional truss, only two-dimensional truss element types are shown on the **Line** tabbed page. A description of the element type T2D2 appears at the bottom of the dialog box. ABAQUS/CAE will now associate T2D2 elements with the elements in the mesh.
6. Click **OK** to assign the element type and to close the dialog box.
7. In the prompt area, click **Done** to end the procedure.

### Creating the mesh

Basic meshing is a two-stage operation: first you seed the edges of the part instance, and then you mesh the part instance. You select the number of seeds based on the desired element size or on the number of elements that you want along an edge, and ABAQUS/CAE places the nodes of the mesh at the seeds whenever possible. For this problem you will create one element on each bar of the hoist.

#### To seed and mesh the model:

1. From the main menu bar, select **Seed**→**Part** to seed the part instance.

**Note:** You can gain more control of the resulting mesh by seeding each edge of the part instance individually, but it is not necessary for this example.

The **Global Seeds** dialog box appears. The dialog box displays the default element size that ABAQUS/CAE will use to seed the part instance. This default element size is based on the size of the part instance. A relatively large seed value will be used so that only one element will be created per region.

2. In the **Global Seeds** dialog box, specify an approximate global element size of **1 . 0**, and click **OK** to create the seeds and to close the dialog box.
3. From the main menu bar, select **Mesh**→**Part** to mesh the part instance.
4. From the buttons in the prompt area, click **Yes** to confirm that you want to mesh the part instance.

**Tip:** You can display the node and element numbers within the Mesh module by selecting **View**→**Part Display Options** from the main menu bar. Toggle on **Show node labels** and **Show element labels** in the **Mesh** tabbed page of the **Part Display Options** dialog box that appears.

## 2.3.9 Creating an analysis job

Now that you have configured your analysis, you will create a job that is associated with your model.

**To create an analysis job:**

1. In the Model Tree, double-click the **Jobs** container to create a job.  
ABAQUS/CAE switches to the Job module, and the **Create Job** dialog box appears with a list of the models in the model database. When you are finished defining your job, the **Jobs** container will display a list of your jobs.
2. Name the job **Frame**, and click **Continue**.  
The **Edit Job** dialog box appears.
3. In the **Description** field, type **Two-dimensional overhead hoist frame**.
4. In the **Submission** tabbed page, select **Data check** as the **Job Type**. Click **OK** to accept all other default job settings in the job editor and to close the dialog box.

### 2.3.10 Checking the model

Having generated the model for this simulation, you are ready to run the analysis. Unfortunately, it is possible to have errors in the model because of incorrect or missing data. You should perform a data check analysis first before running the simulation.

**To run a data check analysis:**

1. Make sure that the **Job Type** is set to **Data check**. In the Model Tree, click mouse button 3 on the job named **Frame** and select **Submit** from the menu that appears to submit your job for analysis.
2. After you submit your job, information appears next to the job name indicating the job's status. The status of the overhead hoist problem indicates one of the following conditions:
  - **Submitted** while the job is being submitted for analysis.
  - **Running** while ABAQUS analyzes the model.
  - **Completed** when the analysis is complete, and the output has been written to the output database.
  - **Aborted** if ABAQUS/CAE finds a problem with the input file or the analysis and aborts the analysis. In addition, ABAQUS/CAE reports the problem in the message area (see Figure 2–2).

During the analysis, ABAQUS/Standard sends information to ABAQUS/CAE to allow you to monitor the progress of the job. Information from the status, data, log, and message files appear in the job monitor dialog box.

**To monitor the status of a job:**

1. In the Model Tree, click mouse button 3 on the job named **Frame** and select **Monitor** from the menu that appears to open the job monitor dialog box.

The top half of the dialog box displays the information available in the status (**.sta**) file that ABAQUS creates for the analysis. This file contains a brief summary of the progress of an analysis and is described in “Output,” Section 4.1.1 of the ABAQUS Analysis User’s Manual. The bottom half of the dialog box displays the following information:

- Click the **Log** tab to display the start and end times for the analysis that appear in the log (**.log**) file.
- Click the **Errors** and **Warnings** tabs to display the first ten errors or the first ten warnings that appear in the data (**.dat**) and message (**.msg**) files. If a particular region of the model is causing the error or warning, a node or element set will be created automatically that contains that region. The name of the node or element set appears with the error or warning message, and you can view the set using display groups in the Visualization module.

It will not be possible to perform the analysis until the causes of any error messages are corrected. In addition, you should always investigate the reason for any warning messages to determine whether corrective action is needed or whether such messages can be ignored safely.

If more than ten errors or warnings are encountered, information regarding the additional errors and warnings can be obtained from the printed output files themselves.

- Click the **Output** tab to display a record of each output data entry as it is written to the output database.

### 2.3.11 Running the analysis

Make any necessary corrections to your model. When the data check analysis completes with no error messages, run the analysis itself. To do this, edit the job definition and set the **Job Type** to **Continue analysis**; then, resubmit your job for analysis.

You should always perform a data check analysis before running a simulation to ensure that the model has been defined correctly and to check that there is enough disk space and memory available to complete the analysis. However, it is possible to combine the data check and analysis phases of the simulation by setting the **Job Type** to **Full analysis**.

If a simulation is expected to take a substantial amount of time, it may be convenient to run it in a batch queue by selecting **Queue** as the **Run Mode**. (The availability of such a queue depends on your computer. If you have any questions, ask your systems administrator how to run ABAQUS on your system.)

### 2.3.12 Postprocessing with ABAQUS/CAE

Graphical postprocessing is important because of the great volume of data created during a simulation. The Visualization module of ABAQUS/CAE (also licensed separately as ABAQUS/Viewer) allows you to view the results graphically using a variety of methods, including deformed shape plots, contour plots,

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

vector plots, animations, and  $X$ - $Y$  plots. In addition, it allows you to create tabular reports of the output data. All of these methods are discussed in this guide. For more information on any of the postprocessing features discussed in this guide, consult Part V, “Viewing results,” of the ABAQUS/CAE User’s Manual. For this example you will use the Visualization module to do some basic model checks and to display the deformed shape of the frame.

When the job completes successfully, you are ready to view the results of the analysis with the Visualization module. In the Model Tree, click mouse button 3 on the job named **Frame** and select **Results** from the menu that appears to enter the Visualization module. ABAQUS/CAE opens the output database created by the job and displays a fast plot of the model. A fast plot is a basic representation of the undeformed model shape and is an indication that you have opened the desired file. Alternatively, you can click **Visualization** in the **Module** list located under the toolbar, select **File**→**Open**, select **Frame.odb** from the list of available output database files, and click **OK**.

**Important:** The fast plot does not display results and cannot be customized, for example, to display element and node numbers. You must display the undeformed model shape to customize the appearance of the model.

The title block at the bottom of the viewport indicates the following:

- The description of the model (from the job description).
- The name of the output database (from the name of the analysis job).
- The product name (ABAQUS/Standard or ABAQUS/Explicit) and version used to generate the output database.
- The date the output database was last modified.

The state block at the bottom of the viewport indicates the following:

- Which step is being displayed.
- The increment within the step.
- The step time.


The view orientation triad indicates the orientation of the model in the global coordinate system.

You can suppress the display of and customize the title block, state block, and view orientation triad by selecting **Viewport**→**Viewport Annotation Options** from the main menu bar (for example, many of the figures in this manual do not include the title block).

### Displaying and customizing an undeformed shape plot

You will now display the undeformed model shape and use the plot options to enable the display of node and element numbering in the plot.

From the main menu bar, select **Plot**→**Undeformed Shape**; or use the  tool in the toolbox. ABAQUS/CAE displays the undeformed model shape, as shown in Figure 2–11.




**Figure 2–11** Undeformed model shape.

**To display node numbers:**

1. From the main menu bar, select **Options**→**Undeformed Shape**.  
The **Undeformed Shape Plot Options** dialog box appears.
2. Click the **Labels** tab.
3. Toggle on **Show node labels**.
4. Click **Apply**.

ABAQUS/CAE applies the change and keeps the dialog box open.

The customized undeformed plot is shown in Figure 2–12 (your node numbers may be different depending on the order in which you sketched the frame members).




**Figure 2–12** Node number plot.

**To display element numbers:**

1. In the **Labels** tabbed page of the **Undeformed Shape Plot Options** dialog box, toggle on **Show element labels**.
2. Click **OK**.

ABAQUS/CAE applies the change and closes the dialog box.

The resulting plot is shown in Figure 2–13 (your element numbers may be different depending on the order in which you sketched the frame members).



**Figure 2–13** Node and element number plot.

To disable the display of node and element numbers in the undeformed shape plot, repeat the above procedure and, under **Labels**, toggle off **Show node labels** and **Show element labels**.

**Displaying and customizing a deformed shape plot**


You will now display the deformed model shape and use the plot options to change the deformation scale factor and overlay the undeformed model shape on the deformed model shape.

From the main menu bar, select **Plot**→**Deformed Shape**; or use the  tool in the toolbox. ABAQUS/CAE displays the deformed model shape, as shown in Figure 2–14.

For small-displacement analyses (the default formulation in ABAQUS/Standard) the displacements are scaled automatically to ensure that they are clearly visible. The scale factor is displayed in the state block. In this case the displacements have been scaled by a factor of 42.83.

**To change the deformation scale factor:**

1. From the main menu bar, select **Options**→**Deformed Shape**.



**Figure 2–14** Deformed model shape.

2. From the **Deformed Shape Plot Options** dialog box, click the **Basic** tab if it is not already selected.
3. From the **Deformation Scale Factor** area, toggle on **Uniform** and enter **10.0** in the **Value** field.
4. Click **Apply** to redisplay the deformed shape.  
The state block displays the new scale factor.

To return to automatic scaling of the displacements, repeat the above procedure and, in the **Deformation Scale Factor** field, toggle on **Auto-compute**.

**To overlay the undeformed model shape on the deformed model shape:**

1. In the **Basic** tabbed page of the **Deformed Shape Plot Options** dialog box, toggle on **Superimpose undeformed plot**.
2. Click **OK**.


By default, ABAQUS/CAE plots the undeformed model shape in green and the deformed model shape in white. The plot is shown in Figure 2–15.

**Checking the model with ABAQUS/CAE**

You can use ABAQUS/CAE to check that the model is correct before running the simulation. You have already learned how to draw plots of the model and to display the node and element numbers. These are useful tools for checking that ABAQUS is using the correct mesh.

The boundary conditions applied to the overhead hoist model can also be displayed and checked in the Visualization module.

## EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE




**Figure 2-15** Undeformed and deformed model shapes.

### To display boundary conditions on the undeformed model:

1. From the main menu bar, select **Plot**→**Undeformed Shape**; or use the  tool in the toolbox.
2. From the main menu bar, select **View**→**ODB Display Options**.
3. In the **ODB Display Options** dialog box, click the **Entity Display** tab.
4. Toggle on **Show boundary conditions**.
5. Click **OK**.

ABAQUS/CAE displays symbols to indicate the applied boundary conditions, as shown in Figure 2-16.



**Figure 2-16** Applied boundary conditions on the overhead hoist.

### Tabular data reports

In addition to the graphical capabilities described above, ABAQUS/CAE allows you to write data to a text file in a tabular format. This feature is a convenient alternative to writing tabular output to the data (.dat) file. Output generated this way has many uses; for example, it can be used in written reports. In this problem you will generate a report containing the element stresses, nodal displacements, and reaction forces.

#### To generate field data reports:

1. From the main menu bar, select **Report**→**Field Output**.
2. In the **Variable** tabbed page of the **Report Field Output** dialog box, accept the default position labeled **Integration Point**. Click the triangle next to **S: Stress components** to expand the list of available variables. From this list, toggle on **S11**.
3. In the **Setup** tabbed page, name the report **Frame.rpt**. In the **Data** region at the bottom of the page, toggle off **Column totals**.
4. Click **Apply**.  
The element stresses are written to the report file.
5. In the **Variable** tabbed page of the **Report Field Output** dialog box, change the position to **Unique Nodal**. Toggle off **S: Stress components**, and select **U1** and **U2** from the list of available **U: Spatial displacement** variables.
6. Click **Apply**.  
The nodal displacements are appended to the report file.
7. In the **Variable** tabbed page of the **Report Field Output** dialog box, toggle off **U: Spatial displacement**, and select **RF1** and **RF2** from the list of available **RF: Reaction force** variables.
8. In the **Data** region at the bottom of the **Setup** tabbed page, toggle on **Column totals**.
9. Click **OK**.  
The reaction forces are appended to the report file, and the **Report Field Output** dialog box closes.

Open the file **Frame.rpt** in a text editor. The contents of this file are shown below.

#### Stress output:

**Field Output Report**

**Source 1**

-----

EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

ODB: Frame.odb  
 Step: "Apply load"  
 Frame: Increment 1: Step Time = 2.2200E-16

Loc 1 : Integration point values from source 1

Output sorted by column "Element Label".

Field Output reported at integration points for Region(s) FRAME-1: soli  
 < STEEL >

Element Label	Int Pt	S.S11 @Loc 1
1	1	294.116E+06
2	1	-294.116E+06
3	1	147.058E+06
4	1	294.116E+06
5	1	-294.116E+06
6	1	147.058E+06
7	1	-294.116E+06
Minimum		-294.116E+06
At Element		7
Int Pt		1
Maximum		294.116E+06
At Element		4
Int Pt		1

Displacement output:

Field Output Report

Source 1

-----  
 ODB: Frame.odb  
 Step: "Apply load"  
 Frame: Increment 1: Step Time = 2.2200E-16

EXAMPLE: CREATING A MODEL OF AN OVERHEAD HOIST WITH ABAQUS/CAE

Loc 1 : Nodal values from source 1

Output sorted by column "Node Label".

Field Output reported at nodes for Region(s) FRAME-1: solid < STEEL >

Node Label	U.U1 @Loc 1	U.U2 @Loc 1
1	735.291E-06	-4.66972E-03
2	-975.782E-21	-2.54712E-03
3	1.47058E-03	-2.54712E-03
4	1.47058E-03	-5.E-33
5	0.	-5.E-33
Minimum	-975.782E-21	-4.66972E-03
At Node	2	1
Maximum	1.47058E-03	-5.E-33
At Node	4	5

Reaction force output:

Field Output Report

Source 1

-----

ODB: Frame.odb  
Step: "Apply load"  
Frame: Increment      1: Step Time =    2.2200E-16

Loc 1 : Nodal values from source 1

Output sorted by column "Node Label".

Field Output reported at nodes for Region(s) FRAME-1: solid < STEEL >

Node	RF.RF1	RF.RF2
------	--------	--------

Label	@Loc 1	@Loc 1
1	0.	0.
2	0.	0.
3	0.	0.
4	0.	5.E+03
5	909.495E-15	5.E+03
<b>Minimum</b>	0.	0.
At Node	4	3
<b>Maximum</b>	909.495E-15	5.E+03
At Node	5	5
<b>Total</b>	909.495E-15	10.E+03

Are the nodal displacements and peak stresses in the individual members reasonable for this hoist and these applied loads?

It is always a good idea to check that the results of the simulation satisfy basic physical principles. In this case check that the external forces applied to the hoist sum to zero in both the vertical and horizontal directions.

What nodes have vertical forces applied to them? What nodes have horizontal forces? Do the results from your simulation match those shown here?

### 2.3.13 Rerunning the analysis using ABAQUS/Explicit

We will rerun the same analysis in ABAQUS/Explicit for comparison. This time we are interested in the dynamic response of the hoist to the same load applied suddenly at the center. Before proceeding, click mouse button 3 on **Model-1** in the Model Tree and select **Copy Model** from the menu that appears to copy the existing model to a new model named **Explicit**. Make all subsequent changes to the **Explicit** model (you may want to collapse the original model to avoid confusion). You will need to replace the static step with an explicit dynamic step, modify the output requests and the material definition, and change the element library before you can resubmit the job.

#### Replacing the analysis step

The step definition must change to reflect a dynamic, explicit analysis.

#### To replace the static step with an explicit dynamic step:

1. In the Model Tree, expand the **Steps** container. Click mouse button 3 on the step named **Apply load**, and select **Replace** from the menu that appears.

2. In the **Replace Step** dialog box, select **Dynamic, Explicit** from the list of available **General** procedures.  
Model attributes such as boundary conditions, loads, and contact interactions are retained when replacing a step. Model attributes that cannot be converted will be deleted. In this simulation all necessary model attributes will be retained.
3. In the **Basic** tabbed page of the **Edit Step** dialog box, enter the step description **10 kN central load, suddenly applied** and set the time period of the step to **0.01 s**.

### Modifying the output requests

Because this is a dynamic analysis in which the transient response of the frame is of interest, it is helpful to have the displacements of the center point written as history output. Displacement history output can be requested only for a preselected set. Thus, you will create a set that contains the vertex at the center of the bottom of the truss. Then you will add displacements to the history output requests.

#### To create a set:

1. In the Model Tree, expand the **Assembly** container and double-click the **Sets** item.  
The **Create Set** dialog box appears.
2. Name the set **Center**, and click **Continue**.
3. In the viewport, select the point at the center of the bottom edge of the truss. In the prompt area, click **Done** when you are finished.

#### To add displacements to the history output request:

1. In the Model Tree, click mouse button 3 on the **History Output Requests** container and select **Manager** from the menu that appears.
2. In the **History Output Requests Manager** dialog box that appears, click **Edit**.  
The history output editor appears.
3. Under the **Domain** field, select **Set**. ABAQUS automatically provides a list of all the sets created for a given model. In this case you have created only one set, **Center**.
4. In the **Output Variables** region, toggle off the **Energy** output and click the arrow to the left of the **Displacement/Velocity/Acceleration** category to reveal history output options for translations and rotations.
5. Toggle on **U, Translations and rotations** to have the translations and rotations for the selected set be written as history output to the output database file.
6. Click **OK** to save your changes and to close the dialog box. Dismiss the **History Output Requests Manager**.

### Modifying the material definition

Since ABAQUS/Explicit performs a dynamic analysis, a complete material definition requires that you specify the material density. For this problem assume the density is equal to  $7800 \text{ kg/m}^3$ .

#### To add density to the material definition:

1. In the Model Tree, expand the **Materials** container and double-click **Steel**.
2. In the material editor, select **General**→**Density** and type a value of **7800** for the density.

### Changing the element library and submitting the job for analysis

As will be discussed in Chapter 3, “Finite Elements and Rigid Bodies,” the elements available in ABAQUS/Explicit are a subset of those available in ABAQUS/Standard. Thus, to ensure that you are using a valid element type in your analysis, you must change the element library from which the elements are selected to the explicit element library. ABAQUS/CAE automatically filters the available element types according to the selected element library. After changing the element library, you will create and run a new job for the ABAQUS/Explicit analysis.

#### To change the element library:

1. In the Model Tree, expand the **Frame** item underneath the **Parts** container. Then double-click **Mesh** in the list that appears.  
ABAQUS/CAE switches to the Mesh module.
2. From the main menu bar, select **Mesh**→**Element Type**, select the frame in the viewport, and change the **Element Library** selection to **Explicit**.

#### To create and run the new job:

1. In the Model Tree, double-click the **Jobs** container.
2. Name the new job **FrameExplicit**.
3. Set the **Job Type** to **Full analysis**, and submit the job.

## 2.3.14 Postprocessing the dynamic analysis results

For the static linear perturbation analysis done in ABAQUS/Standard you examined the deformed shape as well as stress, displacement, and reaction force output. For the ABAQUS/Explicit analysis you can similarly examine the deformed shape and generate field data reports. Because this is a dynamic analysis, you should also examine the transient response resulting from the loading. You will do this by animating the time history of the deformed model shape and plotting the displacement history of the bottom center node in the truss.

Plot the deformed shape of the model. For large-displacement analyses (the default formulation in ABAQUS/Explicit) the displaced shape scale factor has a default value of 1. Change the **Deformation Scale Factor** to 20 so that you can more easily see the deformation of the truss.

**To create a time-history animation of the deformed model shape:**

1. From the main menu bar, select **Animate**→**Time History**; or use the  tool in the toolbox.  
The time history animation begins in a continuous loop at its fastest speed. ABAQUS/CAE displays the movie player controls on the left side of the prompt area.
2. From the prompt area, select **Animation Options**.  
The **Animation Options** dialog box appears.
3. Change the **Mode** to **Play Once**, and slow the animation down by moving the **Frame Rate** slider.
4. You can use the animation controls to start, stop, and step through the animation. From left to right, these controls perform the following functions: **play**, **stop**, **first image**, **previous image**, **next image**, and **last image**.

The instantaneous load on the truss causes it to respond dynamically during the 0.01 s of the analysis. You can more closely observe this by plotting the vertical displacement of the node set **Center**.

You can create *X–Y* curves from either history or field data stored in the output database (.odb) file. *X–Y* curves can also be read from an external file or they can be typed into the Visualization module interactively. Once curves have been created, their data can be further manipulated and plotted to the screen in graphical form. In this example you will create and plot the curve using history data.

**To create an *X–Y* plot of the vertical displacement for a node:**

1. From the main menu bar, select **Result**→**History Output**.  
ABAQUS/CAE displays the **History Output** dialog box. To see the complete description of the variable choices, increase the width of the **History Output** dialog box by dragging the right or left edge.
2. Select **Spatial displacement: U2 at Node 1 in NSET CENTER**.
3. Click **Plot**.  
ABAQUS/CAE plots the vertical displacement at the center node along the bottom of the truss, as shown in figure Figure 2–17.

**Exiting ABAQUS/CAE**

Save your model database file; then select **File**→**Exit** from the main menu bar to exit ABAQUS/CAE.




Figure 2–17 Vertical displacement at the center of the truss.

## 2.4 Comparison of implicit and explicit procedures

---

ABAQUS/Standard and ABAQUS/Explicit are capable of solving a wide variety of problems. The characteristics of implicit and explicit procedures determine which method is appropriate for a given problem. For those problems that can be solved with either method, the efficiency with which the problem can be solved can determine which product to use. Understanding the characteristics of implicit and explicit procedures will help you answer this question. Table 2–2 lists the key differences between the analysis products, which are discussed in detail in the relevant chapters in this guide.

### 2.4.1 Choosing between implicit and explicit analysis

For many analyses it is clear whether ABAQUS/Standard or ABAQUS/Explicit should be used. For example, as demonstrated in Chapter 8, “Nonlinearity,” ABAQUS/Standard is more efficient for solving smooth nonlinear problems; on the other hand, ABAQUS/Explicit is the clear choice for a wave propagation analysis. There are, however, certain static or quasi-static problems that can be simulated well with either program. Typically, these are problems that usually would be solved with ABAQUS/Standard but may have difficulty converging because of contact or material complexities, resulting in a large number of iterations. Such analyses are expensive in ABAQUS/Standard because each iteration requires a large set of linear equations to be solved.